

☑ Manually change the pins in these connectors to suit the LR970B

